



VX3200

Get Started Guide



@**metro** Enabled



Full-Color Internal Display



Speakerphone



Voice-Activated Dialing



www.LGUSA.com

VX3200

TRI-MODE

PHONE OVERVIEW



DOWNLOADING @metro CONTENT

The new VX3200 by LG can store downloaded content from **@metro**, an enhanced wireless service that allows you to download applications ranging from games, news, sports information, ringtones, stock quotes and more to your phone.



Downloading New Content from @metro

1. From standby mode, press the **@metro** icon (right) on the Navigation Key and press **OK**.
2. Once the **@metro** page is displayed, select the shopping cart icon and press **OK**. Choose from ringtones, games, e-mail and more.

ACCESSING THE WEB

1. From standby mode, press the **Web** icon (left) on the Navigation Key.
2. Once the web browser is launched, you will see the home page.
3. You can end a browser session by pressing **END** at any time.

Note: The ability to access the web is subject to network service availability.


MESSAGES

Allows you to send a text message with or without graphics and sounds to an e-mail address or phone number.



Sending a Text Message

1. From standby mode, press the **Messages** icon (down) on the Navigation Key and select **New Message** (2).
2. Highlight **Address 1**.
3. Press **Left Soft Key** for **Contacts** to enter a recipient from the **Contacts** (1) or **Recent Call** (2) menu, or use the keypad to enter a new e-mail address or phone number. Up to 10 recipients can be added.
4. Select **Message** and press **OK**. Enter the message (up to 160 characters) using the keypad.
5. To add a pre-programmed message, press **Right Soft Key** for **Options** and select **Insert Quick-Text** (1) and press **OK**.
6. Press **Left Soft Key** for **Send**.



MY METRO

My Metro allows you to check your balance and pay your bill from the convenience of your MetroPCS phone.

Checking Your Bill Balance

1. From the **My Metro** (6) menu, select **Monthly Bill** (1).
2. Press **OK** to view your monthly billing information. This information is populated using SMS.

CUSTOMIZABLE FEATURES



Changing the Call Ringer

1. From the **Settings** (8) menu, select **Sounds** (1).
2. Select **Ringers** (1).
3. Select either **Caller ID** (1), **No Caller ID** (2) or **Restrict** (3).
4. Choose from the list of available default or downloaded ringers, or press right or left on the Navigation Key to select a voice memo as a ringer and press **OK**.

Changing the Wallpaper Image

1. From the **Settings** (8) menu, select **Display** (2).
2. Select **Screens** (3).
3. Select **Wallpaper** (1).
4. Select from the list of default images and press **OK**.
5. Press right or left on the Navigation Key for more images.
6. Press **Left Soft Key** for **Save**.

THE SCHEDULER

The Tools menu allows you to view the calendar, schedule an event, program your handset's alarm clock, and view and compose memos on the notepad.




> Scheduling an Event

1. From the **Tools (7)** menu, select **Schedule (1)**.
2. Highlight the event date using your Navigation Key and press **Left Soft Key** for **Add**.
3. You may set the appropriate start and end times, content, recurrence (if any), alarm and ringer by scrolling to the corresponding field, entering the desired information and pressing **OK**.
4. Press **Left Soft Key** for **Save**.

Recording a Voice Memo

1. From the **Tools (7)** menu, select **Voice Memo (3)**.
2. Press **Left Soft Key** for **New**.
3. Start recording after the tone.
4. Press **Left Soft Key** for **Done** to stop recording. By default, your message will be listed by date and time.

Note: Voice memos are automatically saved under the **Tools (7) > Voice Memo (3)** menu.




RECENT CALLS

> Making a Call From Recent Calls

1. Press the **SEND Key** to view your most recent 30 dialed, received and missed calls.
2. Place a call by selecting the desired entry and press **SEND** to connect.


CONTACTS

The internal phone book is capable of storing up to 300 contacts with up to 5 numbers and 3 e-mail addresses per entry.



> Adding a New Contact Entry

1. From the **Contacts (1)** menu, select **New Number (2)**.
2. Enter the telephone number and press **OK**.
3. Select a label (**Home**, **Home 2**, **Office**, **Office 2**, **Mobile**, **Mobile 2**, **Pager**, **Fax**, **Fax 2** or **None**) and press **OK**.
4. Enter a name for the entry and press **OK**.
5. To set a speed dial, highlight **Speed Dial** and press **OK**.
6. Select or enter a slot number and press **OK**.
7. To set a voice dial, highlight **Voice Dial** and press **OK**.
8. Press **OK (1)**, and follow the voice prompts.
9. Press **Left Soft Key** for **Done**.



> Adding a New Speed Dial

Enables you to dial 98 of your most frequently used numbers. These numbers are stored in your phone book in memory locations 2 through 99. For locations 2 through 9, you can use one-touch dialing and for locations 10 through 99, you can use two-touch dialing. Press and hold the corresponding key(s) to the memory location to be dialed or press a digit, then press **SEND**.

1. From the **Contacts (1)** menu, select **Speed Dials (5)**.
2. Select or enter a slot number and press **OK**.
3. Select a name from the list using the Navigation Key and press **OK**.
4. Select the desired number and press **OK**.




> Adding a New Voice Dial

Allows you to add a voice dial tag to a number in the phone book.

1. From the **Contacts (1)** menu, select **Voice Dials (6)**.
2. Press **Left Soft Key** for **New** and use the Navigation Key to select a contact and press **OK**.
3. Select a number from the entry and press **OK**.
4. Press **OK** to record the voice dial tag by following the phone's prompts.


Note: From standby mode, voice dialing can be initiated by pressing and holding (up) on the Navigation Key for 2 seconds.



> Voice Dial Prompt

1. From the **Settings (8)** menu, select **Voice Services (7)**.
2. Select **Voice Dial Prompt (1)**.
3. Use the Navigation Key to select desired option (**Key press**, **Flip open** or **Disable**) and press **OK**.

OTHER NOTABLE SETTINGS



> Activating Speakerphone

1. From standby mode, press the **Speakerphone** icon (up) on the Navigation Key. "**Speaker On**" will appear on the screen. To deactivate, press the key again and "**Speaker Off**" will appear on the screen.

Unique Call Options


The Actions menu may be accessed during a call by pressing **Right Soft Key** for **Options**.

Record

1. Scroll to **Record (5)** and press **OK** to record a phone call.

Notepad


1. Scroll to **Notepad (6)** and press **OK** to write a memo during a call. From the Notepad, you may select an existing memo or press **Left Soft Key** for **Add** to create a new memo.



> Manner Mode

Use Manner Mode in a public place to disable the ringer and activate Vibrate Mode.

1. From standby mode, activate Manner Mode by pressing the **Manner Mode Key** (for 3 seconds) - the phone will vibrate when activated.
2. When set, "**-Manner Mode- activated**" will appear on the screen.
3. To release Manner Mode, press the key until "**-Normal Mode- activated**" is displayed.



> Adjusting Volume Settings

Ringer Volume: While in standby mode, press the side volume keys to adjust the ringer volume.

Earpiece Volume: During a conversation, press the side volume keys to adjust the earpiece volume.

Silent Mode: While in standby mode, press the lower volume key until it reads Silent to mute all sounds.

MENU TREE

CONTACTS (1)  <ol style="list-style-type: none"> List Contacts New Number New E-mail Groups Speed Dials Voice Dials My Contact Info 	<ol style="list-style-type: none"> Signature Auto View Entry Mode Edit Voice Mailbox # Quick-Text Auto Play 	<ol style="list-style-type: none"> Voice Memo Notepad Ez Tip Calc Calculator World Clock My Media 	<ol style="list-style-type: none"> Call Setup <ol style="list-style-type: none"> Auto Retry Answer Call Auto-Answer One-Touch Dial Voice Privacy Auto Volume TTY Mode 	
RECENT CALLS (2)  <ol style="list-style-type: none"> Dialed Calls Received Calls Missed Calls Erase Calls <ol style="list-style-type: none"> Dialed Calls Received Calls Missed Calls All Calls Call Timer <ol style="list-style-type: none"> Last Call Home Calls Roam Calls All Calls KB Counter <ol style="list-style-type: none"> Received Transmitted Total 	<ol style="list-style-type: none"> Erase All <ol style="list-style-type: none"> Inbox Outbox Saved All 	SETTINGS (8)  <ol style="list-style-type: none"> Sounds <ol style="list-style-type: none"> Ringers Key Tone Volume Alerts Power On/Off Tone Display <ol style="list-style-type: none"> Banner Backlight Screens Menu Style Clocks Theme Color Contrast Fonts Language Power Saver Status Light System <ol style="list-style-type: none"> Select System Set NAM Auto NAM Serving System Security <ol style="list-style-type: none"> Lock Phone Restrict Calls Emergency #s Change Code Erase Contacts Reset Default 	<ol style="list-style-type: none"> Data Settings <ol style="list-style-type: none"> Data/Fax PC Connection Voice Services <ol style="list-style-type: none"> Voice dial Prompt Train Words Location 	
MOBILE WEB (4)  <ol style="list-style-type: none"> Start Browser Web Messages Web Settings <ol style="list-style-type: none"> Prompt Alert Beep 	@metro (5)  <ol style="list-style-type: none"> @metro @metro Information 	PHONE INFO (9)  <ol style="list-style-type: none"> My Phone Number S/W Version Icon Glossary Shortcut Help 		
MESSAGES (3)  <ol style="list-style-type: none"> Voice Mail New Message Inbox Outbox Saved Msg Settings <ol style="list-style-type: none"> Auto Save Auto Delete Callback # Msg Alerts 	MY METRO (6)  <ol style="list-style-type: none"> Monthly Bill Metro Connect MetroPCS Card <ol style="list-style-type: none"> Request Balance Pay Monthly Bill 			
	TOOLS (7)  <ol style="list-style-type: none"> Schedule Alarm Clock <ol style="list-style-type: none"> Alarm 1 Alarm 2 Alarm 3 Quick Alarm 			